

## PREVENTION IS BETTER THAN CURE

Cotting coated fabrics are resistant to most daily wear and tear and comply with DIN EN 15973 norm. With regular maintenance they will retain their original softness and shine:

Clean regularly with a pH neutral soap and a soft brush. Always rinse with clear water. Do not use strong detergents, solvent cleaners, polish, wax, patent chemicals or other products not recommended by Cotting. Some stains like ball pen, coffee, wine, eosin and also jeans should be cleaned immediately to avoid any permanent absorption into the vinyl.

**Be careful: we cannot be held responsible for transfer problems generated by dyes of poor quality. Cotting waives all responsibility for problems arisen out of ignoring the cleaning instructions.**



- Act as fast as possible to remove ink stains, which will quickly become indelible.
- Take particular care with light colours, which are more vulnerable.
- Regularly remove any traces of perspiration.
- Avoid prolonged exposure to sources of heat.

### THE FOLLOWING PRODUCTS ARE STRICTLY FORBIDDEN

- Undiluted alcohol and/or acetone
- All solvents and detergents
- Abrasive cleaning products
- Perchlorethylene
- All types of wax
- Trichlorethylene

Cotting cannot be held responsible in the event of these products being used as they will damage the protective varnish on the coating leaving it brittle.

### MINIMUM REQUIREMENTS :

- Dusting
- Regular cleaning (at least once a week)
- Rinsing with clean water (avoid excess water which may get into seams)



griffine@griffine.com



info@plastibert.be

