

CLEANING AND DISINFECTING AGENTS

Manufacturers	DIVERSEY	ANIOS2	DURR DENTAL	ECOLAB	ECOLAB2	AC Marca	SCHULKE & MAVR GmbH	SCHULKE & MAYR GmbH3		
cleaning products / Griffine range	Divosan ETHA Plus	ANIOS Surfanios Premium	Dürr FD 366	Klercide Sporicidal Active Chloride	Incidin Oxywipe	Sanytol Multi-purpose 94% plant-based	Antifect Extra	Microzid sensitive wipes	Soapy water	Alcohol 50°
АВАКА	×	х	✓	X	X	•	~	 ✓ 	✓	✓
BOEING 2000	X	~	✓	~	 	~	~	~	✓	~
COMETE	x	X	Х	X	x	x	✓	x	 ✓ 	X
DIABOLO CHICK	x	~	 ✓ 	✓	x	x	~	~	~	~
DIABOLO CLUB	x	 ✓ 	x	•	x	~	•	~	 ✓ 	 Image: A second s
ELFORM / DENFORM	x	x	✓	x	~	x	~	x	~	X
ESPRIT	~	х	✓	х	x	•	~	 ✓ 	✓	~
ESPRIT DOTTY	x	х	 ✓ 	x	~	x	~	x	✓	х
ESPRIT DREAM	×	х	✓	x	x	•	 ✓ 	 ✓ 	✓	
FLANEL	~	~	✓	 ✓ 	~	 ✓ 	~	 ✓ 	✓	~
GINKGO	x	х	•	 ✓ 	x	x	X	x	✓	✓
GLOBE	x	~	~	 ✓ 	~	~	~	✓	~	✓
KALYTERA	~	 ✓ 	 ✓ 	x	x	x	×	~	 ✓ 	 ✓
MEDISTAT	x	x	•	•	•	x	X	x	✓	X
MUNDIAL	X	✓	✓	 ✓ 	✓	 ✓ 	✓	✓	✓	X
NEPTUNE	x	~	~	~	~	~	~	~	~	x
PONANT	X	~	✓	~	✓	~	 ✓ 	 ✓ 	✓	X
URBAN	~	x	•	x	•	x	~	•	✓	~
Recommendations	✓ ●	Recommended for the	maintenance of Griffir	recommended, condition e coated fabrics under th ot be kept in prolonged c	ne conditions indicated	l by the supplier.		nce of Griffine coated fab	rics.	

Recommendations	•	Can be used under certain conditions: must not be kept in prolonged contact with our coatings, must be rinsed with water after application.				
	Х	Not recommended for the care of Griffine coated fabrics.				
Test Protocol	The product is applied in the highest concentrations indicated by the supplier. Frequency: Every 30 minutes 10 times a day for 30 consecutive days.					
	A rinse with water is carried out at the end of each day					
Notes	Griffine cannot be held responsible for changes in the formulation of Cleaners/Disinfectants products at the initiative of the manufacturers.					